

MP870 Digital Music Player

Firmware Update Instructions


(Please be sure to back up your files before updating the firmware)

Note:

- a. This procedure will initialize the player, and will restore settings to default values. For the safety of your data, please copy your music, videos, recordings, or other files to a computer.
- b. Please remove any other USB device (excluding : mouse, key board) on your PC to ensure Firmware Upgrade successfully.
- c. DO NOT disconnect the power until the Firmware Upgrade is complete.


Upgrade Procedure:

1. Please turn off your MP870
2. Hold the MP870 "Back" button and connect with your computer. Extract the .ZIP file and then execute "MP870 Firmware Update Utility.exe" on the executable file. **(When installation window pops up , please choose the "Install" button)**



3. After checking the files in MP870 have been backup and releasing the MP870 "Back" button, click

the “OK” button.




4. After several seconds, click the “Begin” button to begin updating the firmware version of your MP870.



5. Once the firmware update has successfully completed, a “Upgrade was successful, the program

will exit! ” message will be displayed in the window. Please click the “OK” button to close the “MP870 Firmware Update Utility”.



6. Please disconnect the MP870 from your computer and restart the MP870. After several seconds, from the MP870 Main Menu, select “Player Information” to confirm the player has been updated to the new firmware. If firmware version **1.XX.XX** is displayed, congratulations! Your MP870 is now updated.